Health Protector

Only a few minutes to improve air quality, sterilize germs, and create a healthier environment to Live in.



Important

Please make sure you read these instructions carefully before using the Health Protector

1. FUNCTIONS

1, **Strengthen body immune system:** Health protector generates anions which help to improve the pulmonary function and myocardial function, also improve sleep, promote the metabolism, and enhance the ability of resistance.

2, **Remove stale smells and odours:** Health protector generates ozone which is a powerful oxidizing agent, it will have oxidizing reaction to harmful toxic ingredients and odours organics in the air, removing bad smells and relieve toxicity, and without any secondary pollution.

3, Remove dust & pollen and Kill bacterias & germs: Anion charged particles neutralize the positively charged particles floating in the air, it is able to eliminate dust, smoke and pollen particles, which carry allergies. (Ozone is a powerful oxidizing agent, it can kill various bacterias & germs in the air.)

4, Prolong food freshness time: Due to ozone's peculiarity of killing various of bacterias & germs from food, with the Health Protector that generates ozone, it prolongs

food freshness time. Parallel to this, as well as eliminates the pesticides on the fruit and vegetables skins.

2. FEATURES



- 1. Protection Cover
- 2. Press Button
- 3. Tri-colour LED Light Guide (Blue, Green, Red colours)
- 4. DC Plug
- 5. Battery Cover

3. Accessories (Adaptor pictures only for reference)



4. OPERATING INSTRUCTION

※ 4-AA Batteries Operating

- 1. Remove the battery cover on the back of Health Protector, install 4 pcs "AA" 1.5V high-quality alkaline batteries (purchase separately)
- 2. Press the button, the unit runs with an automatic cycle of 2 mins ON, 40 mins OFF. During the ON period LED emits green-colour continuously and during the OFF period it blinks with green-colour.
- 3. If you press the button once again, the unit will restart and run with the cycle of 2 mins ON, 40 mins OFF.
- 4. To turn off the unit, press for 3 seconds. LED will blink with red-colour twice which means the unit is switched off.
- 5. If LED blinks with red-colour, it means the batteries are low and need to be changed, the unit still works under such condition, but not as well as with new batteries.

*** Adapter With USB Cable Operating**

- 1. Connect adapter to the unit with USB cable, then plug the adapter into the mains socket 100-240VAC, 50/60HZ.
- 2. Press the button, the unit will work continuous (mode 1) automatically and LED emits blue-colour continuously.
- 3. Press the button once again, the unit runs in to an automatic cycle of 2 mins ON, 40mins OFF (mode 2). During the ON period LED emits green-colour continuously and during the OFF period it blinks green-colour.
- 4. If you press the button once again, the unit goes into mode1 again, and then press the button again, it goes into mode2. Use the button to change from mode 1 to mode 2 or back again.
- 5. To turn off the unit, press the button for 3 seconds. LED will blink red-colour twice which means the unit is switched off.

※ Attention:

- 1. When you change from external power to internal battery operation, you need to restart the unit by pressing the button. Or the reverse.
- 2. As soon as plugging- in adapter, external power supply way is priority over battery way.
- 3. If press the button for 10 seconds, the unit will go into testing mode with an automatic cycle of 5 seconds ON, 6 seconds OFF, in this case, please switch off the unit and switch it on again. The unit will go into normal modes.
- 4. The battery operating mode only work when the power cable is removed from the unit.

5. Technical parameter

Rated Voltage	5V	Rated Power	<0.2W
Operating R.H range	5-85%	Operating temperature range	5-45 ℃
Ozone concentration	<0.05ppm	Ion concentration	=2x10 ⁶ pcs/cm ³
	(50cm distance)		(10cm distance)

6. Caution

- 1. When LED blinks with red-colour, please replace the batteries in time to avoid battery leakage. Batteries with the capacity over 2500mah are recommended to use.
- 2. Remove the batteries if you leave the unit unused for a long time.
- 3. Keep the unit away from water.
- 4. Refrigerator ambient is available to use. Not freezer.
- 5. Do not remove the protection cover when the unit works.

7. Guarantee

This product warranty period is 1 year after invoice date excluded the situations such as improper use or man-made damage.

